

ACS RP ACS R ACS A

Automatic pitch control

Faster onto the plane and the bow is kept down at all speeds



Automatic roll control

Crosswinds and uneven loading is automatically corrected



Manual control

Manual control of the trim tabs



Tab position display

The tab position is estimated and displayed for all kinds of trim tabs



Turning detection

Automatic control is suspended while turning




For all sea conditions

The automatic control adapts to varying sea conditions



Automatic retraction

The trim tabs are retracted to prevent marine growth




Off the plane sleep

Automatic control is suspended while off the plane



Direct connection

The trim tabs are connected directly to the control panel



Separate control unit

Optional flybridge panel available

